

Quick Switch Includes: 1 Quick Switch

Helium/Nitrogen Regulator

View a demonstration of the Quick Switch on Conwin's Tools of the Trade DVD

## **Connecting the Quick Switch**





Attach the Quick Switch to either the back of Duplicator 2 or Dual Sizer by snapping on the press fit connection.



Connect the primary hoses to the Quick Switch by snapping the primary regulator hose from the helium tank into the side marked "He" and the primary regualtor hose from the nitrogen tank into the side marked "N<sub>2</sub>".



helium tank. Make sure the cylinder is



Slowly open the cylinder valve. Make sure the valve is fully opened. The cylinder pressure will read on the gauge located on the primary regulator. The inlet pressure will read on the adjustable regulator gauge located on the back of the unit.



To switch between helium and nitrogen, simply use the control switch to open the flow of gas.



#### **Disconnecting the Quick Switch**

- 1. Close both cylinder valves firmly.
- 2. Release pressure by pressing down on the Auto Fill Foil Outlet.
- To remove the hoses from the Quick Switch slide the brass sleeve on the quick disconnect fitting towards the hose and the fitting will release.

## Service & Warranty

For assistance with service & repair issues, or for warranty information, please visit **ConwinOnline.com**, or call **(818)246.9233** 



CONWIN INC. 4510 Sperry Street • Los Angeles, CA 90039 Phone (818) 246-9233 FAX (818) 246-6862



# Conwin's **Portfolio Builders**

#### **Update Your Portfolio!**

A picture is worth a thousand words. Is your portfolio up to date on the latest? Conwin's Portfolio Builder images are the perfect solution for making winning presentations to your clients. Thirty-two photo quality images are available in the full series.



Visit www.ConwinOnline.com today!